
COOKTOP PARTS

For Models: MER6755AAS26 (Stainless)


30" ELECTRIC FREESTANDING SELF CLEAN RANGE NON-CONVECT OVEN



lllus.	Part	
No.	No.	DESCRIPTION
1		Literature Parts
	8101P630-60	Installation
		Instructions
	8113P741-60	Owners Manual
	9762761	Brochure, Tips
		Safe Cooking
2	W10187838	Element (RR,LR)
3	8016P022-60	Glide, Main Top
4	W10204679	Element (RF)
5		Cooktop `
	5706X501-09	Black
6	W10187838	Element (LF)
7	8004P093-60	Support, Element
8	8255P412-60	Block, Element Support

CONTROL PANEL PARTS


For Models: MER6755AAS26 (Stainless)



Illus. No.		DESCRIPTION	Illus. No.		DESCRIPTION	Illus No.		DESCRIPTION
1		Support, Backguard	5	3801F844-51	Bracket, Control	12	7101P434-60	Screw
	3807F734-70	Black Left	6	7407P136-60	Light, Indicator	13	W10166967	Control, H3 (Elec)
	3907F733-70	Black Right	7		Knobs (4)	14		Switch, Infinite
2	7730P011-60	Lens, Indicator		7737P232-60	Black		7403P373-60	LR,RR
3		Panel, Control	8	3604F387-51	Shield, Sight		7403P372-60	LF, RF
	7704P001-60	Stainless	9	4005F803-51	Cover, Rear Wire	15		Overlay
4	7101P633-60	Screw	10	7101P500-60	Screw		7728P500-60	Black
			l 11	3604F405-51	Shield, Wire			

CHASSIS PARTS

For Models: MER6755AAS26 (Stainless)



CHASSIS PARTS


For Models: MER6755AAS26

(Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1	8026P082_60	Extension, Vent	15		Bracket	30	4022W017-45	Vent, Oven
2		Spacer, Side Panel		3801F705-51	Right	31		Vent, Box
3		Screw, Shoulder		3801F706-51	3		4006W129-45	•
4	71011 010-00	Panel, Side	16	4002F332-51			4006W139-45	
7	2618F194-70		17		Oven Light Assy	32	7101P375-60	
5			18	7101P376-60		33		Bracket, Pwr Sply
		Brack, Anti–Tip	_			34		Seal, Frame
6		Cover, Access	19		Screen, Smoke	_		
/		Bracket, Cooktop	20		Bulb, Oven	35		Plug, Hole
8		Foot, Leveler (4)	21	7101P485-60		36		Trim, Kickplate
9	4003F070-51	Base, Gemini	22	8036P012-60	Sheild, Cord	37	7101P633-60	
10		Sensor, Oven	23	3807F580-51	Support, Lwr Oven	38	7450P108-60	Switch, Assy
	7430P044-60	Upper Oven	24		Light Assy.			
	7430P042-60	Lower Oven		7407P181-60	Lower/Upper	INS	ULATION	
11		Spacer, Top	25	209429	Lens, Bulb			
	8010P088-60	•	26		Latch, Door Lock			Insulation, Wrap
	8010P087-60	5	27		Bottom, Burner Box		7002P490-60	Upper Oven
12	7101P388-60			4011F524-51	•			Lower Oven
13		Cover, Bottom Wire		4011F525-51				Insulation, Back
14		Cover, Dollon Wife Cover, Upper Wire	28	7201P089–60			7002P434-60	Upper Oven
14	W 1010/412	Cover, Opper wire	29					Lower Oven
			1 29	30U4F333-31	Sheild, Door Lock	l	10021 200-00	LOWGI OVGII

UPPER DOOR PARTS

For Models: MER6755AAS26 (Stainless)




UPPER DOOR PARTS

For Models: MER6755AAS26 (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.		DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	7103P141-60 7201P091-60 7902P521-60	Lining, Door Nut, Snap Black Gasket, Door Glass, Inner (2) Frame, Glass	6 7 8 9 10	7002P488-60	Baffel, Door Insulation, Door Retainer, Glass Kit, Door Glass (Incl. Foil Tape)	13 14 15	7701P526-60 7902P751-60 7101P675-60	Glass, Oven Door Handle, Door Glass, Outer Door Screw, Handle (2) Hinge, Door (2) Screw (4)

LOWER DOOR PARTS

For Models: MER6755AAS26 (Stainless)




LOWER DOOR PARTS

For Models: MER6755AAS26 (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
1 2	7701P526-60	Handle, Door Kit, Door Glass (Incl. Foil Tape)		W10162384	Screw, Handle Gasket, Door	12 13	7002P246-60 7103P141-60	Insulation, Door Nut, Snap
	7760P154-60 7101P388-60 7101P208-60	Stainless	8 9 10	7101P376-60 7902P436-60 3804F265-45	Bracket, Glass Screw Glass, Inner (2) Bracket, Inner Baffle, Door	15	2402W312-19 7106P141-60	Lining, Door Hinge, Door (2) Shield, Door

RACK AND ELEMENT PARTS

For Models: MER6755AAS26 (Stainless)



No.	No.	DESCRIPTION
1	7801P159-60	Rack, Upper
2	7801P173-60	Rack, Lwr Oven (2)
3	7406P428-60	Element, Bake
		Lower
4	3807F494-45	Support, Broil
		Element
5	7406P205-60	Element, Broil
6	3807F749-45	Support, Broil
		Element (Upper)
7	7406P474-60	Element, Broil
		(Upper)
8	7101P376-60	Screw
9	7406P427-60	
		(Upper)

OPTIONAL PARTS (NOT INCLUDED)

For Models: MER6755AAS26 (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.

Illus. Part No. No. DESCRIPTION

Following Parts Not Illustrated

REFINISHING MATERIAL

799832 Kit, Porcelain

Repair (White) 242756 Touch-Up

Self-Clean(1/2 Pt)

INSULATION

261514 Insulation,

Fiberglass (1–1/2" x 24" x 120")

240132 Insulation,

Fiberglass (2-1/2" x 22" x 120")

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72032 Black 511873 White Porcelain

(2 Oz.)

PAINT, PRESSURIZED SPRAY

(12 oz.)

350939 Black

285006 Superior Black

62069220 Primer (White)

PAINT, BULK (1 qt.)

799340 Black (Uncut)

Illus. Part

No. No. DESCRIPTION

ACCESSORY PARTS

241430 Foil, Aluminum

Oven (18" x 25')

WIRING HARNESS PARTS

5171P909-60 Harness, Main Harness, Inf.Sw.

5171P910-60 Left

01/1P91U-0U Leil 5474D044 60 Diab

5171P911-60 Right

5171P467-60 Harness, Side

Mount Lock

5171P462-60 Harness, Sensor

5175P365-60 Harness, Door

Position

8019P026-60 Clip, Harness

7101P027-60 Screw, Ground

8019P013-60 Clip, Wire

7401P157-60 Blocks, Bare Wire

Adapter (Kit of 3)

W10261617